
BUILDING OWNERS



WHEN TO CHECK

MONTHLY

Check your fire extinguishers

- None are missing or damaged
- Extinguishers are visible and accessible
- Pressure gauge pointer is in the green zone
- Tamper seal not missing or broken

ANNUALLY

A trained extinguisher technician performs service on all fire extinguishers to ensure they are in proper working order in accordance with the manufacturer's manual.

PERIODICALLY

Internal Examination & Hydrostatic Testing (pressure testing of the containers) should be done




A trained extinguisher technician internally examines components of pressurized extinguishers (every 3, 5, or 6 years, depending on type) and replaces worn parts in accordance with the manufacturer's manual.

HYDROSTATIC TESTING

A trained extinguisher technician removes extinguishers to **perform nondestructive pressure tests** (every 5, or 12 years, depending on type). Loaner extinguishers replace removed extinguishers until work is complete and original extinguishers are returned.

WHEN TO RECHARGE

- After anv use
- Pressure gauge pointer is out of green zone
- Tamper seal missing or broken





WHEN TO REPLACE

A trained service technician can determine if an extinguisher is obsolete, damaged and unusable, or can't be serviced in accordance with the manufacturer's manual.

AND REMEMBER...

BE PREPARED

Have an emergency plan, conduct periodic fire drills, make sure your fire extinguishers are inspected and serviced.

RECAE

In the event of a fire, call 911 and begin to evacuate the building.

BE KNOWLEDGEABLE

When a fire is discovered during its early stage, grab the nearest extinguisher and remember the word PASS: Pull the pin. Aim at the base of the fire. Squeeze the operating lever. Sweep the discharge from side to side.

BE CONFIDENT

You can rest assured that your fire extinguishers are usable during a fire emergency when installed and serviced by a trained technician.

